


















Runde Schalter/round push button

Funktion/ function	Symbol/ symbol	Modell/ model	Farbe/ colour	ET-Liste, Pos.-Nr./ spare part list-no.
Ein/Aus on/off		 T1	blau blue	1
Start start	START	 T3	blau blue	2
Regenerierung regeneration		 T3	blau blue	3
Kaltspülung cold rinse button		 T3	blau blue	4
Laugenpumpe drain pump		 T3	blau blue	5
Reinigungszyklus washing cycle		 T3	grün green	6
Temperatur temperature		 T3	grün green	7
Blindkappe neutrally plug			grau grey	8
Träger, 2-fach double support			grau grey	9
Träger, 3-fach triple support			grau grey	10



SOLO MACCHINE DEPURATE O POMPA SCARICO
 DEPURATION MACHINE OR DRAIN PUMP
 AVEC MACHINE ADOUCISSEUR D'EAU O POMPE DE VIDANGE




MACCHINE STANDARD
 STANDARD MACHINE
 MACHINE STANDARD




40401






Optional






VERSIONE STANDARD / VERSIONE POMPA AUM. PRESSIONE
STANDARD VERSION / BOOSTER PUMP VERSION
VERSION STANDARD / VERSION POMPE AUGMENT. PRESSION






















SEKO**SEKO****TECNOPRO****MICRODOS****GERMAC****LANG**

5120



5110

