

Pflege und Aufbewahrung

Reinigen Sie das Messer direkt nach dem Gebrauch mit einem feuchten Tuch!

1. Messer niemals ungereinigt liegen lassen – besonders nach dem Umgang mit säurehaltigen Nahrungsmitteln.
2. Messer niemals mit ätzenden oder scheuernden Mitteln reinigen.
3. Messer mit Holzgriff weder in der Spülmaschine reinigen, noch im Wasser liegen lassen.
4. Messer niemals lose in der Schublage lagern.
5. Niemals Schneidunterlagen aus Stein oder Keramik verwenden, da dies die Klingen beschädigt und stumpf werden lässt.

Care and Maintenance

Clean your knife after each use with a damp cloth!

1. Never put your knife away without wiping it clean – specially after cutting acidic foods.
2. Never use acidic or abrasive cleansers to scrub your knife.
3. Knives with wooden grips are NEVER to be washed in the dishwasher or left soaking in standing water!
4. Never store your knife loose in a drawer.
5. Never use a cutting surface made from stone or ceramic as these will dull or damage the cutting edge.



GLÜDE
die Messer